



Fixing and finishing instructions for *Primer Mould + Plus* Veneered MDF Mouldings

Fixing instructions

To make the best of this premium product, it is preferable to glue it to the wall with a gap filling adhesive. In the majority of circumstances, skirting boards can be fixed in this way, however, should you need to use screws to fit the product, then oak pellets can be supplied to cover the screw head.

Pellets are 12mm in diameter and therefore require an appropriate counter bore to be drilled. **Please note:** the oak veneer and oak pellets are a natural product and as such will not necessarily exactly match for grain structure or colour.

Architrave can again be fitted using a gap filling adhesive but may also need to be secured with a few lost head nails which should be punched below the surface and filled over with an appropriate coloured wood filler.

Window Board can be fitted by screwing through the Window Board and concealing the screws with oak pellets. Iron on oak strip is available for the exposed ends if required.

Finishing

Veneered profiles can be treated just like timber; they can be finished in a wax, Danish oil, acrylic lacquer or any normal wood stain product that is appropriate for timber.

We do not recommend using water based stains and finishes. When varnishing or lacquering, the veneered surface may darken in colour.

Points to Note

Due to the wood veneer being a natural timber product, colour variations may occur between batches of veneers. As with real wood, high levels of exposure to direct sunlight can lead to discolouration.

Health and Safety

As with all timber products we recommend the use of dust control equipment when cutting, sawing or drilling. Always work within a well ventilated area and where extraction is impractical wear protective face masks and eye protection.